

UPC-700 (Universal Portable Camcorder) User Manual Rev1.0



1. Bag



2. USB Cable



3. OTG Cable



<Option>

4. Adapter for car



5. Adapter for AC



6. Sling



7. Velcro



8. Plastic clip



9. Metal clip



10. Waterproof sticker



1. Stand alone to use (no connected to USB cable)

- (1) Photography mode : Press the "Top button" once, blue lights → about 4 to 5 seconds then also press "Top button" to start (Blue light flashing), if not then continue to press the "Top button" will flashing on start.
 - (2) Turn off : Video status (blue light flashing) or standby status (blue lights), the long press "Top button" to see the blue lights in emergency flash 2 times → release button, to shutdown state (blue light goes out).
 - (3) Suspended (standby) mode: blue lights alone, means the suspended mode, if there is no action after, blue lights will automatically turn off after 60 seconds.
 - (4) Take a picture : Video or standby status, press to "Bottom button", is photographed action (blue light flashes once), then back to the standby mode.
- *Note: During the video to press "Bottom button" video will stop, want to photography again must press again to "Top button" and let the blue lights flashing.


2. While connected to the USB cable :

- (1) If connected to room electric (110V / 220V), car charger (12V), mobile power bank (5V), this status is charge while recorded, Red light and blue lights flashing, if you want to shut down the power, remove the cable directly can be.
- (2) If connected to the computer or smartphone, this is for read the information standby mode, red and blue light or only blue light, if you want to shut down the computer or smartphone must follow the procedure of unload memory required.
- (3) Charge mode : When connected to the USB cable, whether video while charge status or standby status, long press the "Top button" to see the blue lights in emergency flash 2 times → release button, this is charging status (red light, blue light off) after fully charged, the red light will automatically turn off.

3. Data reads

- (1) Computer reads the data: the USB cable to the computer (red and blue light, or just blue light) → the screen appears removable disk information, → please open the folder to view files, → safely release hardware after reading
- (2) Smartphone (android) reads data : phone download APP (MX Player or KM Player or Dice Player) First find the Video Player, → then connected OTG cable, → connected to smartphone USB slot (red and blue light) The screen show that USB device installation completed → read data after follow the procedure to release the device.

- *Note :
- a. When read data from smartphone, hearing sound only but no video, need to press the " hardware decoding" and press the "software decoding" again.
 - b. SD card no need format action, if do that will let SD card can't record, SD card must do the program of repair process.



4. Battery power checking :

Press the voltage-button to view the voltage, voltage indicator just lights green light, indicating that electricity can also be maintained for at least two hours, When the red and green are lit, indicating that power is insufficient (up to two hours), please timely supplement electricity.

5. Reset button :

When LED (blue light) can't off, or other unknown conditions can't be controlled, press the Reset button, make the product back to the initial state.

Cautions :

- A. When the lack of electricity, device will automatically power off and timer will lead to confusion, the time need to re-set is required. Re-set information : <http://www.haihao.com.tw/camhelmet.files/time.html>
- B. SD card repair program : <http://www.haihao.com.tw/product/SDcardrepair.doc>
- C. When not in use device, be sure to check that all lights are off, so as to not to consume electricity.

Two Years Warranty

Made in Taiwan

BSMI

FCC

CE

RoHS

IPX7

HaiHao

www.haihao.com.tw