

1. Product Statement :

1. 產品定義 :

- A. Helmet (Main Product) is a stand alone product, and passed some regulations safety test, like DOT, ECE, CNS
- A. 安全帽(主要產品)是獨立的個體, 它有通過一些安規的測試, 如 DOT, ECE, CNS---
- B. Visor (internal built-in Wiper Module) is add-on parts for helmet (belong to After Market product), user can put on or take off it by himself for free.
- B. 帽舌(內建有雨刷模組)它屬於安全帽的附加物(售後市場的產品), 使用者可以輕易的自我安裝.



A. Helmet
A. 安全帽



B. Visor
B. 帽舌

2. Set-up to Wiper Helmet :

2. 組裝成雨刷安全帽



Step I : Remove both sides of screw from the shield pivot
步驟 I : 扭開位於鏡面兩邊轉軸的螺絲



Step II : Take the visor cover the shield
步驟 II : 將帽舌蓋在鏡面上

Step III : Get visor and helmet together then fasten the screw, on helmet top and both sides
步驟 III : 將帽舌與安全帽組合, 並將位於安全帽頂端與兩側螺絲分別鎖緊




Step IV : Open the liner and put into the batteries
步驟 IV : 打開內襯並且將電池放入



Battery : AA*4

3. Operation : 3. 操作說明 :

A. Button Control A. 按鍵操控




- * Power switch : Turn on the power, can hear Beep sound and indicator light lamped
電源開關 : 電源打開後, 會聽到嗶一聲及電源指示燈亮起
- * Red button(Continuous mode) : Continual swip and press any button to stop
紅色按鍵(連續模式) : 連續刷動, 按任意鍵即停止
- * Green button(Intermittant mode) : Swip once every 4 seconds and press any button to stop
綠色按鍵(間歇式刷動模式) : 每間隔4秒刷動一次, 按任意鍵即停止

* Power switch : Turn on the power, can hear Beep sound and indicator light lamped
電源開關 : 電源打開後, 會聽到嗶一聲及電源指示燈亮起




B. Remote Control B. 遙控操控



- * Red button(Continuous mode) : Continual swip and press any button to stop
紅色按鍵(連續模式) : 連續刷動, 按任意鍵即停止
 - * Blue button(Intermittant mode) : Swip once every 4 seconds and press any button to stop
藍色按鍵(間歇式刷動模式) : 每間隔4秒刷動一次, 按任意鍵即停止
 - * Green button(Touch mode) : One touch one swip
綠色按鍵(觸控模式) : 按一次刷動一次
- Fasten or stick to the handlebar 置於車把手上

4. Change Wiper Blade 4. 更換雨刷刮刀



- A. Take off the blade A. 取下雨刷刮刀
- * Press the frame top point of wiper-arm and squeeze both sides of blade to remove the blade
壓緊雨刷臂前端的突出點, 左右搖動刮刀將刮刀取出



B. Put on the blade to helmet B. 組裝雨刷刮刀於安全帽上

- * Make sure put the indicator arrow-head to down position of blade
請確認將刮刀上有箭頭的部位朝下
- * Insert in the frame from the blade pivot
將刮刀的轉軸處斜插入刮刀架內

WARNING
ONLY SELECT THE MODE WHEN VEHICLE COMPLETE STOPED FOR YOUR OWN SAFETY CONCERN

警告:為了您的安全
請不要在行駛中
選擇操作模式

- ◎ When wiper doesn't swip properly, suggest to replace the batteries
當發覺雨刷刷動不完整時, 請更換電池
 - ◎ Suggests remove the batteries when not use
不用時, 建議將電池取出
- www.haihao.com.tw