

# UWD-800 User Manual

## 1. Check packing 檢查包裝內容



Device main body 雨刷器主體



Remote control box 遙控器



Wiper-arm 雨刷臂



Reserve foot 預留腳架



Pads 墊高環




Batteries (Option) 電池(選購)

## 2. Clean-up 清潔



Wash & wipe helmet & sucker  
清洗, 擦拭安全帽及吸盤



## 3. Install battery 裝電池



## 4. Setup wiper-arm 裝雨刷臂




## 5. Adjustment the device 調整雨刷器



Testing of device vs. shield position  
測試雨刷器與鏡片的位置



### If necessary : extension the device-head 若需要延伸雨刷器頭時



Release the cover screws  
解開雨刷器蓋的螺絲



Open the cover and release the head screws to adjust head position  
打開蓋子及解開螺絲就可以伸縮雨刷頭位

### If necessary : rise the device-head 若需要提高雨刷器頭時

Pad 墊高環



### If necessary : extension the wiper-arm 若需要延伸雨刷臂時

Press here



### If necessary : adjust the rear foot 若需要調整後腳架

Press here



### Option : 3 feet 選項 : 3隻腳




### Option : 5 feet 選項 : 5隻腳



## 6. Fasten the device

Put a little water on each sucker

每個吸盤抹一點水



### Press to each sucker tightly

壓緊每一個吸盤



### Lock

鎖上螺帽



### CAUTION

- a. When doesn't use this device, please take off the device and batteries
- a. 當不使用時, 請脫下雨刷器及電池
- b. If repeated to use, press sucker before
- b. 如果重複使用時, 必須先壓緊吸盤
- c. When sucker was unclean, please wash the sucker by water
- c. 當吸盤不乾淨時, 請用水沖洗乾淨

## 7. Operation

Fasten control box to the handlebar  
遙控器綁在車把上



### Power on the device

- Continuous swing, press any key to stop  
連續刷動, 按任何鍵可停止
- Intermittent swing, each swing wait for 4 sec. and press any key to stop  
間歇刷動, 每次間隔4秒刷動一次
- One swing of one touch  
按一次刷動一次

## 8. Disassembly & Package



Loosen the screw, pull the sucker up  
鬆開螺絲及將吸盤拉高

### Wiper-arm 雨刷臂



### Package finished 包裝完成



### Change the blade 更換刮刀



Arrow sign 箭頭標誌